

# Easy Folding Instruction For Origami CD Case

**Title, Description,  
Production Details**

## Front

(artwork goes upside down.)

**Cover art credits**

1

2

7

8

3

NOTE:  
Dots and  
numbers  
won't show  
once you fold  
up the case.  
See video on  
how to fold at  
(coming soon).

4

5

6

# **EASY FOLDING INSTRUCTIONS FOR ORIGAMI PAPER CD CASE**

By Michele Fry

**8.5" X 11" sheet of paper. Folds in 3 minutes or less.**

**Print Page 1, making sure your paper margins are set as close to 0 as your computer/printer allows.**

- 1. Place any CD over the Cover Art, making sure it fits well within the square made by Lines 1, 2, 3, and 4. (Due to printer variations, you may have to adjust your folds slightly to get a 1/16<sup>th</sup> inch clearance all around the CD.) Set CD aside.**
- 2. Flip page over horizontally, and fold in on lines 1 and 2 so the lines show on the outside of each crease. Run CD through trough to make sure it clears. If not, adjust folds slightly. Press creases down.**
- 3. Fold in on line 3 so the line shows on the outside of the crease. Make sure CD still clears as you fold Line 4. Leave a 1/16<sup>th</sup> clearance.**
- 4. Fold at Lines 5 and 6 to form equilateral triangles in the upper corners. Numbers will be inside the folds. Press creases down.**
- 5. At this point you may put glue on the blue areas, press, and your case is ready. *BUT, to make an authentic Origami case, proceed as follows:***
- 6. Unfold everything. Fold Line 3.**
- 7. With Line 3 folded and using Lines 7 and 8 as guides, fold corners in (so Line 3 runs along Lines 1 and 2), to form equilateral triangles. Numbers will be inside the fold. Press creases down. Unfold everything.**
- 8. Fold Line 3 backwards (with line inside fold) and crease ends firmly. Unfold.**
- 9. Refold Lines 1 and 2.**
- 10. Fold each triangle at Line 3 so the two green dots touch, and tuck each flap down towards backside of cover art, hospital corner style, creating a box.**
- 11. Now push in at Numbers 7 and 8, forcing the case to fold in and stay folded.**
- 12. Fold in on lines 5 and 6.**
- 13. Fold in on Line 4 and press crease down.**
- 14. Slip the CD into the case, just behind the Title Page, curl and tuck the flap in over the CD.**

**Tip: If you wish, you may put glue on the blue areas to ensure your CD case does not come apart. Glue stick dries quickly, and is less messy than Elmers or Rubber Cement.**

## **NOTES:**

- 1. The front cover square may be slightly oversized to accommodate shrinkage in some printers. Adjust your folds accordingly.**
- 2. Once folded, none of the numbers or dots will be visible on the outside.**
- 3. See Librivox Wiki, CD Covers, for video instructions on how to fold this case. Visit [www.librivox.org](http://www.librivox.org)**

# Pictorial View of Numbered Instructions

1



2



3



4




5



7




8



11



12




True Origami -  
doesn't come apart!



CD goes in this slot!

15



Curl and tuck.

NOTE: Once you memorize how to fold this CD case, you will no longer need the lines. All you'll need is a sheet of 8.5 x 11 paper and a CD. See my video at (coming soon)



Make fancy Origami CD covers for your favorite LibriVox audiobooks using public domain artwork and text provided by our talented volunteers. See video at xxx.